


RESIDENTIAL FLOOR

WITH FOIL DOUBLE BUBBLE rFOIL™

- Quick, easy and simple to install
- Provides reflective insulation for radiant heat loss or gain and adds R value
- Creates an excellent vapor barrier
- Unaffected by moisture and humidity

FOIL Double Bubble rFOIL™



INSTALLATION METHOD:

- 1) Unroll rFOIL™ horizontally along the floor.
- 2) Staple to corner joists and then again on the side of the joist as in illustration.
- 3) Continue to staple along the floor ensuring that rFOIL™ is recessed into the wall cavity 1/2" - 3/4".
- 4) Seal joints with rFOIL™ Regular FOIL Tape.
- 5) Install floor deck as usual.

Suggested products to use in this application:

Ultra rFOIL	• 1220-48-125
rFOIL	• 2220-48-125
Tape	• 15213

*All tape should be applied using a flat edge taping tool to ensure good adhesion.

Check local building codes for compliance before installation. These installation drawings are intended solely to illustrate the proper location and placement of rFOIL Insulation Products in specific construction applications. They are not intended to illustrate proper construction methods, which is ultimately the responsibility of the builder or contractor. The installation instructions are only recommendations relating to the location and installation method of rFOIL Insulation Products, and InsulationStop.com makes no claims that these construction systems are universally accurate. IMPORTANT INFORMATION: The information cited is in good faith and has been established from sources held to be secure and reliable. The values listed are typical properties and are not intended to be used as specifications for defined applications. User must determine the product suitability for the end use application and assume all risks and liabilities. 11/17/99



www.insulationstop.com

(518) 867-9555